

GETTING TO KNOW YOUR ULTIMATE HAMMER TOOL.

KIKKERLAND®



- ▶ The HAMMER works best when other tools are stowed.
- ▶ To use the PLIERS: release clip at the bottom of handle.
- ▶ BLADE, SCISSORS, SCREWDRIVER, and SAW should be opened one at a time. Unfold each blade or tool until it locks in place (180°).
- ▶ To release the locking mechanism: partially open another blade or tool (90°). Then fold tools back to closed positions.



- ▶ DON'T DO IT! Don't open all four of these blades because they'll lock in the open position and it may cause you to lose joy.



- ▶ BUT IF YOU DO then use a flathead screw driver to pry up the locking mechanism. Then you can re-stow the open blades.
- ▶ As with any tool, please be careful.