



A	Top Panel	1
B	Left Panel	1
C	Right Panel	1
D	Bottom Panel	1
E	Partition	2
F	Back Panel	1
G	Foot	2
H	Cushion	1


Please review the hardware listed on the next page as well as individual components of this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.




**H1 x 4
CAM BOLT**




**H2 x 4
CAM**



**H3 x 18
DOWEL**




**H4 x 16
TRUSS HEAD
SCREW**




**H5 x 4
CAM COVER**




**H6 x 4
BOLT**



**H7 x 4
LOCK
WASHER**








**H8 x 4
WASHER**




**H9 x 1
ALLEN
WRENCH**

TOOLS REQUIRED: PHILLIPS SCREWDRIVER




STEP 1



H3 x 8
DOWEL

STEP 2



H1 x 4
CAM BOLT



H2 x 4
CAM





H3 x 10
DOWEL



H5 x 4
CAM
COVER

STEP 3



H6 x 4
BOLT




H7 x 4
LOCK
WASHER




H8 x 4
WASHER


STEP 4



H4 x 16
TRUSS HEAD
SCREW

STEP 5





WARNING: Do not exceed the recommended weight limits on the designated panels. Exceeding these limits could cause sagging, possibly resulting in failure of product or bodily injury. Severe injury may occur if furniture tips over. Never allow children to climb or play on this product. Place heaviest items on lower shelves and as far back as possible, never overload product.